

FITTING INSTRUCTIONS FOR MANTEC RAISED AIR INTAKE TO LAND ROVER DISCOVERY 200/300Tdi/RANGE ROVER

Preparation

1. Mark left wing using template provided.

Removal of Outer Wing

2. Carefully remove the following and retain all pieces
 - i) Nut and bolt that joins wing to bumper
 - ii) Front indicator light housing
 - iii) Nut and bolt that joins wing to the front of the sill
 - iv) Nuts and bolts to door edge and top of wing section
3. Outer wing can now be carefully detached

Fitting Raised Air Intake

4. Remove air cleaner and
5. Hold Air Intake Tube in place-top bracket to gutter-bottom bracket to hole in the inner wing.
6. Secure Air Intake Tube using nuts and bolts provided.
7. Attach rubber elbow between bottom of Air Intake Tube and the air cleaner creating a join. Tighten clips.
8. Cut out marked shape from the outer wing allowing it to be refitted around the Air Intake Tube.
9. Press wing safety edging into the cut.
10. Refit outer wing using retained parts.
11. Attach filter box to top of Intake Tube with the mesh face directed towards the rear of the vehicle. Secure using self-tapping screws provided.